

9



SKODA

Octavia, 5-dr Hatchback, 97-00, 01-04

Octavia, 5-dr Estate, 98-00, 01-04

SEAT


Toledo II, 4-dr Sedan, 98-04



SEAT

Léon I, 3-dr Hatchback, 99-05

Léon I, 5-dr Hatchback, 99-05



SEAT

7 Kg + xx kg = **Max. 60 kg**

SKODA

7 Kg + xx kg = **Max. 75 kg**

Warning: Speed limit 80-130 km/h

Warning: Use tape for securing cargo.

THULE ONE KEY SYSTEM

- 544
- 596
- 588

THULE SWEDEN

SKODA

Octavia, 5-dr Hatchback, 97-00, 01-04

Octavia, 5-dr Estate, 98-00, 01-04

SEAT

Toledo II, 4-dr Sedan, 98-04

Léon I, 3-dr Hatchback, 99-05

Léon I, 5-dr Hatchback, 99-05

- GB** Fitting instructions
- D** Montageanleitung
- F** Instructions de montage
- NL** Montage-instructies
- I** Istruzioni per il montaggio
- E** Instrucciones de montaje
- PT** Instruções de Montagem
- S** Monteringsanvisning
- FIN** Asennusohje
- EST** Paigaldusjuhend
- LAT** Stiprināšanas instrukcija
- LIT** Pritvirtinimo instrukcijos
- PL** Instrukcja montażu
- RU** Инструкции по установке
- CZ** Návod na montáž
- SK** Návod na montáž
- SLO** Navodila za pritrjevanje
- HR** Uputa za sastavljanje
- HU** A felszerelés módja
- GR** Οδηγίες συναρμολόγησης
- TR** Montaj talimatları
- 中文** 安装说明
- 日本語** 取扱(取付)説明書
- 한국어** 장착 지침
- ไทย** คำแนะนำการติดตั้ง



4305

430500

Follow me...

THULE SWEDEN

Box 69, 330 33 Hillerstorp, SWEDEN
www.thule.com

742*3DF2/501-6456-09



THULE

GB Safety regulations
 D Sicherheitsvorschriften
 F Instructions importantes
 NL Veiligheidsvoorschriften
 I Norme di sicurezza
 E Reglas de seguridad
 PT Normas de segurança
 S Säkerhetsföreskrifter
 FIN Turvallisuusohjeet
 EST Ohutusjuhised
 LAT Drošības noteikumi
 LTJ Saugumo taisyklės
 PL Zasady bezpieczeństwa
 HU Biztonsági előírások
 CZ Pokyny pro bezpečnost
 SK Bezpečnostné predpisy
 SLO Varnostni predpisi
 HR Priručnik sigurnosti
 HU Biztonsági előírások
 GR Κανονισμοί Ασφαλείας
 TR Güvenlik kuralları
 ru Инструкция по безопасности
 uk Інструкція з безпеки

